

NAME

mab – move to a given incident and reflected angle

SYNOPSIS

mab *alpha beta*

DESCRIPTION

The mab macro is used to set a surface diffractometer to a given angle of incidence *alpha* and to position the detector at a given angle of reflection *beta* (in the plane of incidence) with respect to the surface. It does not necessarily move the detector into the plane of incidence.

EXAMPLE

mab 10mr 10mr

SEE ALSO

mr mk wait